CRANE OPERATOR (LEVEL LUFFING JIB)

Competency Standards Code: I63S009
Source: National Competency Standard
National Certificate at NVQ Levels in the occupation of CRANE OPERATOR (LEVEL LUFFING JIB)

Will be awarded to those who are competent in

Unit 01+02+03 - I63S009Q1L3 – Level 3



NATIONAL APPRENTICE AND INDUSTRIAL TRAINING AUTHORITY,
No.971, Sri Jayawardanapura Mawatha, Welikada,
Rajagiriya.

Telephone. 0112888782-7 **Email: naitaitd@yahoo.com**

Unit of competency	Element Number	Elements of Competence
01. Prepare crane for operation I63S009U01	**1.1**	Carry out walk- aroundinspection and make readyfor operation
	1.2	Carry out walk- aroundinspection for machineryhouse and make read
	1.3	Perform visual inspection on A - frame & Jib
	1.4	Carry out operator's cabininspection and make readyfor operation
	1.5	Keep records
02. Ensure proper attaching of lifting gears & equipment with load I63S009U02	**2.1**	Confirm the weight of the load & the balance
	2.1	Confirm lifting gears & equipment
03. Handle the load I63S009U03	**3.1**	Lift the load
	3.2	Move the load
	3.3	Position the load
	3.4	Park the crane